
LITETRONICS®

Area Light Trunnion Mount (ALATM)

Installation Instructions



SAFETY INSTRUCTIONS AND WARNINGS

- When using electrical equipment, basic safety precautions should always be observed.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Installation should only be conducted by a qualified electrician in accordance with NEC and any relevant local building codes.
- Be certain electrical power is OFF before and during installation and maintenance.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or sharp objects.

WHAT COMES IN THE BOX

REQUIRED TOOLS

Allen Wrench

Trunnion Mount

M8 * 20mm (x4)

M8 * 16mm (x2)

M5 * 12mm (x2)

(N) 12111111 (A2

Spring Washer M8 (x6)

Flat Washer M8 (x6)

Ground Washer M8 (x2)

Expansion Bolts (x2)

Installation Instructions

INSTRUCTIONS

Before Installation, carefully remove all parts from the packaging. Inspect product for defects due to shipping.

Always turn off the power supply from main circuit breaker first!

TRUNNION MOUNT INSTALLATION

1. Open the mount head. (Figure 1)

Base


Mount head

M5 screw


M8 screw

Figure 1

2. Affix base with screws and lock on to the fixture. (Figure 2)




3. Pass the wires through the trunnion mount head. (Figure 3)



- Finish the wire connection accordingly (refer to area light installation instructions for wiring diagram).
- Align the fixture to required angle. Tighten M5 screw and M8 screw after the angle is confirmed. (Figure 4)





Thank you for choosing

LITETRONICS®

6969 W. 73rd Street Bedford Park, IL 60638

WWW LITETRONICS COM

CustomerService@Litetronics.com or 1-800-860-3392





The information and product specifications contained in these instructions are based upon data believed to be accurate at the time of printing. This information is subject to change without notice and without incurring liability. If you have questions regarding specific product details, please contact us at 800-860-3392 or via email at customerservice@litetronics.com. To check for an updated version of these instructions, please visit www.litetronics.com.